



METHOD OF WIDENING APPROACHES TO DUAL STRUCTURES

NOTES:

ON FULL SHOULDER WIDTH BRIDGES, NO WIDENING IS TO BE PROVIDED.

X₁ AND X₂ = AMOUNT OF BRIDGE WIDENING PER SIDE (10' MAXIMUM).

* IF BRIDGE DRAINAGE APRONS ARE REQUIRED THE PAVEMENT WIDENING IS TO BE APPLIED AT THE END OF THE DRAINAGE APRON FARTHEST FROM THE ABUTMENT BACKWALL.

SPECIFICATION REFERENCE
NONE

METHOD OF WIDENING BRIDGE APPROACH PAVEMENT

VIRGINIA DEPARTMENT OF TRANSPORTATION