

## RURAL CONDITION

RURAL CONDITIONS APPLY TO INTERSTATE, ARTERIAL, PRIMARY AND SECONDARY SYSTEMS OR TO ANY OTHER ROAD WITH RURAL TYPE DESIGN AND OPERATING CONDITIONS.

THESE TABLES CONTAIN SUPERELEVATION AND WIDENING CORRECTIONS FOR STANDARD RURAL PAVEMENT WIDTHS THROUGH A RANGE OF RADII AND DESIGN VELOCITIES CONSIDERED MOST LIKELY TO BE USED IN RURAL HIGHWAY DESIGN.

DEFINITIONS FOR THE STANDARD SYMBOLS USED THROUGHOUT THESE TABLES ARE FOUND ON SHEET 801.01.

FOR MINIMUM DESIGN FACTORS FOR VARIOUS DESIGN SPEEDS FOR RURAL CONDITIONS SEE SHEETS 801.30 THRU 801.40.

ON CURVES WITH GREATER THAN 2865 FT RADIUS THERE WILL BE NO SPIRAL TRANSITION OR PAVEMENT WIDENING. PAVEMENT WILL BE SUPERELEVATED BY AN AMOUNT EQUAL TO THE RATE SHOWN IN THE TABLES. SEE SHEET 801.05 FOR A GRAPHICAL ILLUSTRATION OF THE APPLICATION OF THIS CORRECTION.

ON CURVES WITH PAVEMENT WIDTHS OF 24' OR WIDER AND A RADIUS OF 881 FT. OR GREATER, THERE WILL BE NO SPIRAL TRANSITION OR PAVEMENT WIDENING. PAVEMENT WILL BE SUPERELEVATED BY AN AMOUNT EQUAL TO THE RATE SHOWN IN THESE TABLES.

FOR CURVE RADII NOT LISTED IN TABLES REFER TO SHEET 801.18 TO CALCULATE TRANSITION LENGTHS (LS) AND PAVEMENT WIDENING (w).

LS AND E SHOULD BE SHOWN ON THE PLANS FOR ALL CURVES..

FOR GRAPHICAL ILLUSTRATION OF DESIGN SUPERELEVATION RATES FOR RURAL CONDITIONS SEE SHEET 801.16.

FOR ADDITIONAL GENERAL INSTRUCTIONS (BOTH URBAN AND RURAL) SEE SHEET 801.04.

EXPLANATION OF TABLES AND INSTRUCTIONS FOR USE  
RURAL CONDITION

VIRGINIA DEPARTMENT OF TRANSPORTATION