

Trns'port PES

Project M009PM6B12345

page 1 page 2

UNIQUE UPC (FROM POOL) AT END OF PCN

ADD "C" IN FRONT WHEN YOU BUILD THE PROPOSAL

STATE PROJECT NUMBER AS GENERATED BY POOL

PCN: M009PM6B12345

Proposal ID: CM009PM6B12345

Item Code Table: 07

State Project Number: PM6B-059-F09-P401

Description: 2009 PLANT MIX SCHEDULE

FREDERICKSBURG DISTRICT

Location: SALUDA RESIDENCY

Unit System: E

Federal Project No.: NONE

Route Number: PM6B

Status: CON1

Road Section No.: F09

Const. Eng. Pct.: 12.00

Co./City: 059

DISRES: 0637

Federal Oversight: N/A

MEDIAN: N/A

Beginning Station:

Project Work Type: MAR

Ending Station:

Project Type: SR

ADD CM PREFIX - OPTIONS SHOWN IN DROPDOWN MENU

USE SCHEDULE NUMBER HERE

ROAD SECTION IS THE FISCAL YEAR THE PROJECT STARTS

USE THE COUNTY WHERE RESIDENCY IS LOCATED

MAR- PLANT MIX  
MSS- SLURRY SEAL  
MST- SURFACE TREATMENT

Ready

Set up the PCN with the unique UPC.

Set up the State project number as generated by the pool in iPM.

Set up the Proposal ID (PCN with a C at the front)

Route number line should have the schedule number (first four digits of the State project number)

Road Section is the Fiscal Year the project should start.

City/County is the county the residency is located.

Project Work Type (for schedule work only) should be MAR (plant mix), MSS (slurry seal/latex) or MST (surface treatment).

Project type should (again for schedule work) have a CM prefix (IE...CMSS, CMSR, CMMS or CMMR).