



**METHOD OF WIDENING APPROACHES TO DUAL STRUCTURES**

NOTES:

ON FULL SHOULDER WIDTH BRIDGES, NO WIDENING IS TO BE PROVIDED.

$X_1$  AND  $X_2$  = AMOUNT OF BRIDGE WIDENING PER SIDE (10' MAXIMUM).

\* IF BRIDGE DRAINAGE APRONS ARE REQUIRED THE PAVEMENT WIDENING IS TO BE APPLIED AT THE END OF THE DRAINAGE APRON FARTHEST FROM THE ABUTMENT BACKWALL.

THIS DRAWING WAS VOID WITH THE JULY 2013 R&B STANDARDS REVISION

SPECIFICATION REFERENCE	METHOD OF WIDENING BRIDGE APPROACH PAVEMENT	 ROAD AND BRIDGE STANDARDS
NONE	<p><b>VOID</b></p> VIRGINIA DEPARTMENT OF TRANSPORTATION	