

TRANSITION TABLE

LENGTH OF TANGENT RUNOUT (Lt)	START/END OF SUPERELEVATION RUNOFF (Lr)	DISTANCE IN METERS FROM START/END OF SUPERELEVATION RUNOFF SECTION (Lr)				NORMAL CROWN
		1	2	3	4	
65	0	13	26	39	52	65
60	0	12	24	36	48	60
55	0	11	22	33	44	55
50	0	10	20	30	40	50
45	0	9	18	27	36	45
40	0	8	16	24	32	40
35	0	7	14	21	28	35
30	0	6	12	18	24	30
25	0	5	10	15	20	25
20	0	5	10	15	————	20
12	0	6	————	————	————	12

NOTE:

TABLE LISTS POSTIONS ON TRANSITIONS AT WHICH SLOPE STAKES SHOULD BE SET,
CONSTRUCTION AND FINAL CROSS-SECTIONS TAKEN, FINE GRADING STAKES (BLUE TOP)
SET, AND FORM STAKES SET (CONCRETE PAVEMENT ONLY).

SUPERELEVATION RUNOFF (Lr) / TANGENT RUNOUT (Lt) TABLE

SPECIFICATION
REFERENCE