



Notes:

All exposed concrete surface edges shall be chamfered 3/4".

Anchor bolts and bolt circle template shall be furnished with cabinet. Cabinet shall be centered on foundation.

Each foundation shall be permanently marked to indicate all sides from which conduits pass. This mark shall be made with a trowel when finishing the concrete and shall be 1/4" deep and 4" to 6" long. Locations of empty conduits shall have an additional 2" long mark made perpendicular to and centered on this marking.

The controller cabinet at the inside and outside foundation joints shall be sealed with a silicone sealant.

Bell ends shall be installed on each end of PVC conduits. Empty conduits shall be plugged to prevent moisture and rodent entry.

Grounding bushings shall be installed on each end of metal conduits. Empty conduits shall be plugged to prevent moisture and rodent entry.

Two - 1/2" diameter weepholes shall be provided in the foundation and located 2" inside of the back or side edges of the controller cabinet. Weepholes shall be sloped to allow outlet to be 3" below top of foundation. Two inches of the outlet end shall be fiber filled.

VOIDS remaining after conductors exit or enter bell ends or bushings of conduits shall be sealed with silicone to prevent moisture or rodent entry.

SPECIFICATION REFERENCE

CONTROLLER CABINET FOUNDATION AND CONDUIT PLACEMENT DETAILS