

TC-5.01

CURVE WIDENING TABLES

SU DESIGN VEHICLE

COMPONENT	SIZE
OVERALL WIDTH (w)	8.0 ft
WHEELBASE (L)	20 ft
FRONT OVERHANG (A)	4 ft

LATERAL CLEARANCE

LANE WIDTH	CLEARANCE (C)
9 ft	1.5 ft
10 ft	2 ft
11 ft	2.5 ft
12 ft	3 ft
16 ft	5 ft

ADJUSTMENT FACTORS

NUMBER OF LANES ROTATED n_1	ADJUSTMENT FACTOR (b_w)
1	1.00
1.5	0.8333
2	0.75
2.5	0.70
3	0.6667
3.5	0.6425

RELATIVE GRADIENTS

DESIGN SPEED V_D MPH	MAXIMUM RELATIVE GRADIENT (rg)	MIN. TRANSITION LENGTH IN FEET RURAL CONDITIONS WITH PAVEMENT WIDENING AND REVERSE CURVES FOR ALL CONDITIONS
		(2 SECOND RULE)
20	0.74	59
25	0.70	74
30	0.66	88
35	0.62	103
40	0.58	117
45	0.54	132
50	0.50	147
55	0.47	161
60	0.45	176
65	0.43	191
70	0.40	205

- A - FRONT OVERHANG OF DESIGN VEHICLE FROM APPROPRIATE TABLE.
- b_w - ADJUSTMENT FACTOR FROM TABLE.
- C - LATERAL CLEARANCE OF DESIGN VEHICLE FROM APPROPRIATE TABLE.
- E - SUPERELEVATION RATE FROM APPROPRIATE TABLE.
- F_A - CALCULATED WIDTH OF OVERHANG FOR DESIGN VEHICLE.
- L - WHEELBASE OF DESIGN VEHICLE FROM APPROPRIATE TABLE.
- LS - LENGTH OF SPIRAL OR SUPERELEVATION TRANSITION LENGTH.

DEFINITIONS

- M - MULTIPLE LANE FACTOR.
- N - NUMBER OF LANES.
- n_1 - NUMBER OF LANES ROTATED (FROM TABLES).
- P_w - PAVEMENT WIDTH.
- R - RADIUS OF CURVE.
- rg - RELATIVE GRADIENT FROM APPROPRIATE TABLE.
- U - CALCULATED TRACK WIDTH OF DESIGN VEHICLE.

- u - TRACK WIDTH OF DESIGN VEHICLE FROM APPROPRIATE TABLE.
- V_D - DESIGN VELOCITY.
- w - CALCULATED WIDENING.
- W - PAVEMENT WIDTH
- W_C - CALCULATED TOTAL CURVE WIDTH.
- W_n - WIDTH OF LANE.
- Z - CALCULATED EXTRA WIDTH ALLOWANCE.

GENERAL DESIGN CONSIDERATIONS

1. WHERE PAVEMENT WIDENING IS REQUIRED, THE APPROPRIATE WIDENING IS ADDED TO THE LANE WIDTH WHEN CALCULATING THE TRANSITION LENGTH (LS).
2. THE COMPUTED TRANSITION LENGTH (LS) IS ROUNDED UP TO THE NEAREST FOOT.
3. WHEN THE TRANSITION LENGTH (LS) IS CALCULATED, IT MUST BE COMPARED WITH THE MINIMUM VALUE LISTED IN THE APPROPRIATE COLUMN ON THE RELATIVE GRADIENT TABLE.
4. CROWN RUNOFF IS ALWAYS ACHIEVED OUTSIDE OF THE TRANSITION.
5. NO PAVEMENT WIDENING IS REQUIRED FOR URBAN ROADWAYS.
6. NO PAVEMENT WIDENING IS REQUIRED FOR RURAL ROADWAYS WITH A CURVE RADIUS GREATER THAN 2865 FEET.
7. NO PAVEMENT WIDENING IS REQUIRED FOR RURAL ROADWAYS WITH 12 FOOT WIDE LANES AND A CURVE RADIUS GREATER THAN 881 FEET.
8. PAVEMENT WIDENING IS APPLIED ONLY WHEN CALCULATED WIDENING (w) IS EQUAL TO OR GREATER THAN 2 FEET.
9. WHEN CALCULATING WIDENING (w) FOR MULTI-LANE RURAL ROADWAYS, WIDENING IS FIRST CALCULATED USING THE SINGLE LANE WIDTH FOR "W".
10. AN ALTERNATE METHOD FOR MULTI-LANE UNDIVIDED PAVEMENTS (48'). THE LS IS 1.5 TIMES (M=1.5) THE CORRESPONDING LENGTH FOR TWO LANE HIGHWAYS; AND FOR SIX LANE UNDIVIDED PAVEMENTS (72'), THE LS IS TWO TIMES (M=2) THE CORRESPONDING LENGTH FOR TWO LANE HIGHWAYS.
11. CALCULATED WIDENING IS ROUNDED UP TO THE NEAREST 0.1 FOOT.
12. CURVES WITH SPIRAL CURVE TRANSITIONS MUST HAVE A MINIMUM TRANSITION LENGTH (LS) EQUAL TO 2 SECONDS OF TRAVEL TIME AT THE ROADWAY'S DESIGN SPEED AS NOTED IN THE RELATIVE GRADIENT TABLE.

NO WIDENING REQUIRED FORMULAS USED TO CALCULATE TRANSITION LENGTH (LS) AND WIDENING (w)

$LS = b_w(W_n n_1 E / rg)$

$LS = M(WE / rg)$ (ALT. MULTI-LANE)

WIDENING REQUIRED

$LS = b_w[E n_1 (W_n + w/N) / rg]$

$LS = m[E(W + w/N) / rg]$ (ALT. MULTI-LANE)

$$U = u + R - \sqrt{R^2 - L^2}$$

$$F_A = \sqrt{R^2 + A(2L + A)} - R$$

$$Z = (V_D / \sqrt{R})$$

$$W_C = N(U + C) + F_A + Z$$

$$w = W_C - 2W_n$$

FOR SOLVED PROBLEMS USING THIS METHODOLOGY, SEE THE EXAMPLES ON PAGE 802.23

METHODOLOGIES FOR CALCULATING TC-5.01 VALUES