



NOTE:

- 1. COMPUTE STRAIGHT LINE WIDENING AND SUPERELEVATION TRANSITION FROM MAXIMUM OF FIRST CURVE TO MAXIMUM OF SECOND CURVE.
- 2. REFER TO CHAPTER 3 OF THE AASHTO'S <u>A POLICY ON THE GEOMETRIC DESIGN OF HIGHWAYS AND STREETS</u> FOR ADDITIONAL REVERSE CURVE DESIGN INFORMATION.
- 3. REVERSE CURVES SHOULD HAVE A CURVE LENGTH THAT ALLOWS ADEQUATE DEVELOPMENT OF THE FULL SUPERELEVATED SECTION OF PAVEMENT FOR EACH CURVE.

****VDOT

ROAD AND BRIDGE STANDARDS

SHEET 1 OF 1 803.12 REVISION DATE

METHOD OF APPLYING TC-5.11 ON REVERSE CURVES RURAL CONDITION WITH PAVEMENT WIDENING

VIRGINIA DEPARTMENT OF TRANSPORTATION

SPECIFICATION REFERENCE